





DC Charging Adapter Instructions

The SmartHub needs to be connected to the mains power as follows:

Part 1 – Connecting DC Adapter to Timeclock

Inset the pin-shaped end of small DC adapter cable into the small circular slot on right hand side of the Timeclock – please see following image:



The Adapter should be inserted into the device as seen in the image here (please note depending on the model of device the charging port could be located on the opposite side as shown)



Version: 2.0





Part 2 – connecting Micro USB Charging Unit to DC Adapter

Inset Micro USB side of the charging unit into the Micro USB slot of the DC Adapter – please see following image.



The result should be the same as seen in the image here.



Version: 2.0 2 | Page